




Spare Parts List(MAIN ASSY)				
Ref ID	HARMAN Part NO.	Description	Qty	SKU
1	5123676-00	HDW,NPL,LOGO ABS PA -75 94HB BLACK	1	
2	5123677-00	MECHASY,GRL,SPCC NA TUR COLOR,IRX108	1	
6	5123678-00	AUD,LS,SPEAKER,8 IN,PAPER FE ST BT 40	1	
11	5123679-00	HDW,HDL,HANDLE SIDE ASSY,IRX 108	1	
13	5123703-00	ENCL,REAR PLATE EVA A 38° ADH,IRX108BT	2	
14	5123704-00	ENCL,REAR PLATE EVA B 38° ADH,IRX 108BT	2	
16	5123705-00	PCB,ASY,AMPLIFIER ASSY,NA	1	IRX108BT_NA
	5126372-00	PCB,ASY,AMPLIFIER ASSY,CN	1	IRX108BT_CN
	5123706-00	PCB,ASY,AMPLIFIER ASSY,EU/AU	1	IRX108BT_EU IRX108BT_AU
18	5123707-00	HDW,HDL,HANDLE TOP ASSY,IRX108	1	
24	5123709-00	ANT,ANTENN,495.4M,50 OHM	1	
25	5125452-00	AUD,LS,TWEETER,25MM CPRSN TI 4O	1	
28	5123711-00	CBL,PCRD,JRK-348A,320 +300MM,4PIN,108bt	1	



Powered 8" Portable Speaker with Bluetooth



Spare Parts List(REAR PLATE ASSY)				
Ref ID	HARMAN Part NO.	Description	Qty	SKU
2	5123712-00	PCB,ASY,TST,INPUT,IRX108BT	1	
3	5123713-00	OPT,LENS,EVA A 38' ADHESIVE,IRX 108BT	1	
4	5123729-00	HDW,KNOB,BUTTON ON OFF ABS PA-75 BLK	3	
5	5123731-00	HDW,KNOB,BUTTON EQ ABS PA-75 BLK	1	
6	5123732-00	HDW,KNOB,BUTTON PWR BT ABS PA-75 BLK	1	
7	5123718-00	OPT,LENS,B PC-110 94HB TRANS	1	
8	5123719-00	OPT,LENS,A PC-110 94HB TRANS	1	
9	5123720-00	ENCL,PLATE REAR SECC NATUR COLOR,NA	1	IRX108BT_NA
	5126374-00	ENCL,PLATE REAR SECC NATUR COLOR,CN	1	IRX108BT_CN
	5123721-00	ENCL,PLATE REAR SECC NATUR COLOR,EU/AU	1	IRX108BT_EU IRX108BT_AU
11	5123723-00	HDW,KNOB,MASTER ABS PA-75 94HB BLACK	1	
12	5123724-00	HDW,KNOB,VOLUME ABS PA-75 94HB BLACK	2	
14	5126245-00	THRMMGT,THRMPD, SILICONE H400	1	
15	5123725-00	CBL,2P JUMPER CABLE UL1672 #16	1	
18	5123727-00	CON,JMPR,JRK- 346A 60MM 1PIN	1	
19	5126371-00	PCB,ASY,TST,SMPS & AMP,IRX108BT	1	
20	5123735-00	HDW,PLUG, 250VA 10A NA LECI	1	
21	5126246-00	HDW,INSUL,THRM, H160-ISPO5 GREY	1	
23	5123736-00	HDW,KNOB,EQ BUTTON EVA 48' BLK,IRX112BT	1	
24	5123737-00	HDW,KNOB,BUTTON POWER EVA 48' BLK,IRX112BT	1	

