

PROFESSIONAL

by **HARMAN**Service Manual

VLA-C125S-GR
Dual 15" Subwoofer with
Differential Drive






Table of Contents

Datasheet and Specs
Exploded View
Bill of Materials

JBL Professional Engineering

Loudspeaker Engineering Design Specification Date Effective: 8/6/2018

Date Revised: 8/6/2018

Number 1000313448

Page 1

11

GENERAL DESCRIPTION

MODEL: VLA-C125S

DESCRIPTION: Dual 15", Subwoofer

SYSTEM COMPONENTS

LF 5029733 2275H x2 (EDS #1000098313)

ACOUSTICAL AND ELECTRICAL SPECIFICATIONS

Sensitivity – Raw pass bands See attached curves, page 2

Frequency Response (-3dB) 62Hz – 123Hz (4π , LF Preset) 100Hz – 1.9 kHz (4π , Raw) Frequency Response (-6dB) 57Hz – 158Hz (4π , LF Preset) 73Hz – 3.0 kHz (4π , Raw) Frequency Response (-10dB) 52Hz – 210Hz (4π , LF Preset) 51Hz – 3.5 kHz (4π , Raw)

Rated Impedance LF: 4Ω

Minimum Impedance LF: 3.0 Ω @ 195 Hz,

Coverage (-6dB) Omni / 360°

Power Handling with Array preset 80Vrms / 160Vpk @ 100hrs, SMS

Maximum SPL measured with Array Preset $131.3 \text{ dB } 4\pi / 137.3 \text{ dB } 2\pi$

(2m GP, NTI XL2, 12dB CF Pink Noise)

System Input Type Barrier Strip

System Polarity All (+) polarity when driven from (+) pin.

System Protection DSP driven

Speaker DSP File 1000336780

Engineering Test Specification: 1000313449


PHYSICAL SPECIFICATIONS

Enclosure Volume for each LF 3.8 cu.ft. / 107liters

Maximum External Dimensions (in/mm) $20.0/508 \text{ H} \times 33.4/848 \text{ W} \times 24.9/634 \text{ D}$

Weight (ea.) 125 lbs / 56.7 kg

DESIGN ENGINEER



Bill of Materials

Bill of Materials				
Number	Name	Quantity	Unit	
VLA-C125S-GR	S/M, VLA-C125S-GR			
22389P	FBRGL,1"x72",600SF/ROLL	20	Square Foot SF	
315953-001	BAG,ZIPLOCK,9X12	2	each	
352951-001	THREADLOCK, 9 GRAM STICK, LOCTITE 248	0.001	gram	
353210-001	LF WIRE ASSY, PD5322/95 & /64	1	each	
360-70002-01	GASKET, REAR 15"	2	each	
364542-001	WASHER, 3/8x.875 STAINLESS NEOPRENE BACK	28	each	
364835-001	GASKET, ENCLOSURE EON515	10	Lineal Foot	
442545-001	10-32 X 1 1/2 socket head cap screw SS	16	each	
49790P	MICROFOAM 1/32X18X20	8	each	
5018271	Large Plastic Logo, STX800	1	each	
5029733	M/I, 2275H	2	each	
29074A	PRIMER,BOSTIK-1007A	1.1	gram	
311-37002-03	CONE/COMPLIANCE 2265G-1	1	each	
317-30003-01	SPIDER 2266H	1	each	
337035-001	SHORT RING, 2265	1	each	
337966-001	TERMINAL, ASSY NDD	1	each	
339053-002	TINSEL LEAD, 2262H	1	each	
351555-001	CRIMPING MATERIAL, HVNDD, 1015614BCP	2	each	
353219-001	ACTIVATOR, LOCTITE 7091, VARIOUS	0.9	Milliliter	
362891-001	DAMPENER, C.P. MOYEN SP-356	17	gram	
362961-002	VOICE COIL ASSY, 2265H	1	each	
364219-002	ACC, CYBERBOND BLAST 6003 (SAME AS -001)	1.7	gram	
440906-001	ADHESIVE, LOCTITE E120	2.7	Milliliter	
5021936	SHORT RING, FOR 3-INCH COIL	1	each	
5021992	BACK-CASTING, 2275, 2278	1	each	
5021995	POLE PLATE, FOR 3-INCH COIL	2	each	
5021996	CERAMIC MAGNET, FOR 3-INCH COIL	 	each	
5025149	TERMINALS HOLE COVER	1	each	
5031715	LABEL, 2275H	1	each	
5040782	ADH, DENKA, PURESTOR Z-220	5.5	gram	
5042123	ADAPTER, 2275, 2278	1	each	
5042124	TOP PLATE, 2275, 2278	2	each	
63627	ADH,C.A.,SICO-MET	0.2	gram	
71636-36	SHIM, 227X	0.05	Piece	
71646-04	DUST DOME, 2265H,2262	1	each	
71666	ADH, SPEEDBONDER 3270	8.9	ounce	
72266	ADH,SICOMET,5181	3.4	gram	
72591-0099	FRM 15.230OD 5.10ID3.21C/SPD DIST 6STK M	1	each	
73404	GASKET, 15", SELF ADH	4	each	
74822	LBL, DTC	1	each	
72471	RIBBON,XFR,THRM,4.5"x1181	0.2	Meter	
75225	LABEL, BLANK	1	each	
863-41610-10	SCR,8-32 X 5/8,PAN,PH,TT,BLK ZINC,LCS_	2	each	
864-41610-06	SCR,10-24 X 3/8,PAN,PH,TT,BLK ZC,LCS	12	each	
910-00009-00	ADH, 3M3532, URETHANE W/BLK PIGMENT	3.8	ounce	
910-00045-00	ADH, RTV OXIME SILICON RUBBER	0.17	gram	
CONSUMABLES	ADHESIVES/PAINTS/CHEMICALS/LABELS/ETCALL	1.807	Piece	
5057646	GASKET, WATER SEAL, INPUT CUP	1	each	
5057740	GLAND NUT KIT, 1/2", PD500	1	each	
0001170	OD 110 1 M1, 112, 1 D000		Jouon	

5055462	BAG, 2X3, 2MIL, RECLOSABLE, U-LINE S-1291	1	leach
5057643	HEYCO LIQUID TIGHT M3216, W/NUT, FOR 1/2"	1	each
802-11056-08	SCR,6-32 X .5,FLT,PH,SS	4	each
5059045	JUMPER WIRE, GREEN, PD500	1	each
5059046	JUMPER WIRE, GRN/BLK, PD500	1	each
5089027-00	INPUT CUP ASSY, WRX, GRAY	1	each
5089504-00	ENCL,CVR, 1/2" WRX INPUT, GRAY	1	each
5089890-00	CBL,WA,HARNESS-CUP,VLA125S	1	each
5089982-00	LBL,OVERLAY,VLA-C125S	1	each
5089985-00	HYDROMESH, VLA-C125S	1	each
5090286-00	GRILLE, VLA-C125S, LT GRAY	1	each
5090500-00	ENCL,CVR,4-COND,WR,GRA	2	each
5090639-00	FSTNR,WSHR,LKW,M10,SST	28	each
5090640-00	FSTNR,MSCR,TRSSH,PH,8-32X0.5,SST	8	each
5090853-00	HDWR,FOAM STRIP,EDPM,1/2WD,1/16THK	0.04	Piece
5090859-00	SHPMAT,CTN	1	each
5090860-00	SHPMAT,FLR	2	each
5090906-00	FSTNR,MSCR,PNH,PH,8-32X2,SST	14	each
5091587-00	FSTNR,MSCR,6-32X1,PH,TRSSH,SS	8	each
5092804-00	ADH,MULTI PURPOSE,SPRAY,TL	10	gram
5093211-00	HDW, BRKT, SIDE PLATE	2	each
5093243-00	ENCL,GF,GR	1	each
5083794	INNER PLATE, BAFFLE, VLA-C125S	1	each
5083797	INNER PLATE, ENCL, VLA-C125S	2	each
5083836	INNER TRIM, ENC, VLA-C (INPUT CUP)	1	each
5086719	INNER TRIM, 4COND TERM, VLA-C125S	2	each
5089085-00	STIFFENER ASSY, VLA-C125S	1	each
5081027	STIFFENER, BACK, VLA-C125S	1	each
334003-002	PLYWD,BALT,18mm,48"x96"	0.9697	Square Foot SF
5086717	STIFFENER, CENT, VLA-C125S	1	each
334003-002	PLYWD,BALT,18mm,48"x96"	3.2	Square Foot SF
5086718	STIFFENER, SIDE, VLA-C125S	2	each
334003-002	PLYWD,BALT,18mm,48"x96"	4	Square Foot SF
5093690-00	ENC, CVR, FG	2	each
5097116-00	FSTNR,MSCR,FLH,PH,6-32x3/4in,SS	18	each
5100662-00	LBL,UNDERLAY,VLA-C125S-GR	1	each
5082073	LABEL, STOCK UNDERLAY, WRX INPUT CUP	0.0286	Piece
5101180-00	HDW, BRKT, ANGLE, VLA-C125S	2	each
802-11056-08	SCR,6-32 X .5,FLT,PH,SS	2	each
802-51056-20	SCR,6-32 X 1.25,OV,PH,PLAIN	8	each
818-93756-35	M-10 - 1.5 X 35MM BUT HD SOCK C/S 18-8	28	each
CONSUMABLES	ADHESIVES/PAINTS/CHEMICALS/LABELS/ETCALL	1	each