



MACRO-TECH SERIES

AC Power Draw and Thermal Dissipation

The information provided on this page is calculated data based on driving both channels to rated output using the 1 kHz Maximum Average Power rating method.

Other parameters used in calculation include a conservative idle current estimate of 90 watts and a conservative estimate of effeciency at 65%.

Information is provided only for getting an idea of current draw and heat produced. Actual performance will vary depending on environment, program material, load, signal, and AC mains voltage and frequency.

Values of calculated current draw are intended to represent average draw corresponding to the thermal breaker requriements that should be met to handle the amplifier as a load on the AC mains.

Peak current draw with dynamic program material may be significantly higher. Thermal information is provided to assist with calculating air conditioning needs. The data here should not be construed as specifications

Duty cycle of various program material:

Individual speech: 10% Acoustic/chamber music: 20% Full-range rock music: 30% Compressed rock music: 40%

Pink noise: 50%

Here are the equations used to calculate the data presented in Figure 1:

The quiescent power draw is a maximum value and includes power drawn by the fan. The following equation converts power draw in watts to current draw in amperes:

Current Draw (amperes) =
$$\frac{\text{AC Mains Power}}{\text{AC Mains}} \times \frac{\text{Power}}{\text{Factor (.83)}}$$

The value used for Power Factor is 0.83. The Power Factor variable is needed to compensate for the differnece in phase between the AC mains voltage and current. The following equation is used to calculate thermal dissipation:

The value used for inefficiency is 1.00-efficiency. The factor 3.415 converts watts to btu/hr. Thermal dissipation in btu is divided by the constant 3.968 to get kcal. If you plan to measure output power under real-world conditions, the following equation may also be helpful:

Macro-Tech 24x6

	LOAD														
	2 Ohm Stereo / 4 Ohm Bridge					4 Ohm Stereo / 8 Ohm Bridge					8 Ohm stereo / 16 Ohm Bridge				
Duty Cycle	AC Mains Power Draw (watts)	Current Draw (Amps)		Thermal Dissipation		AC Mains Power Draw	Current Draw (Amps)		Thermal Dissipation		AC Mains Power Draw	Current Draw (Amps)		Thermal Dissipation	
		120V	230V	btu/hr	kcal/hr	(watts)	120V	230V	btu/hr	kcal/hr	(watts)	120V	230V	btu/hr	kcal/hr
50%	1205	12.1	6.1	1650	416	955	11.2	5.6	1525	384	663	6.8	3.4	1000	252
40%	982	9.9	5.0	1375	347	782	9.1	4.6	1300	328	548	5.6	2.8	875	871
30%	759	7.7	3.8	1100	277	609	7.1	3.6	1050	265	434	4.4	2.2	725	182
20%	536	5.4	2.7	840	212	436	5.0	2.5	800	202	319	3.3	1.7	600	151
10%	313	3.2	1.6	575	145	263	3.0	1.5	550	139	205	2.1	1.1	450	113



A Harman International Company

Crown International, Inc. 1718 W. Mishawaka Rd. Elkhart, IN 46517-9439 TEL: 574-294-8200

TEL: 574-294-8200 FAX: 574-294-8FAX www.crownaudio.com For more details refer to the applicable Operation Manual or contact Crown Factory Service. The provided data should not be construed as specifications.

Crown and Crown Audio® are registered trademarks of Cown international, Inc. Printed in U.S.A.

©2005 Crown Audio, Inc.

04/05 138356-1