

# AE TECHRON

## LV 3622 AMPLIFIER

### APPLICATION

The LV 3622 is a single channel linear amplifier, specifically designed to drive high impedance loads at high voltage levels. The LV 3622 features isolated inputs and outputs that allow

three LV 3622 amplifiers to be connected in a wye configuration with common neutral for power utility or related applications. The LV 3622's versatility makes it useful in industrial and commercial power applications including power system modeling, shaker tables, low frequency building resonators. The LV 3622's low distortion level makes it ideal for drive actuators, servos and other positioning units. AE Techron's LV 3622 is also used to supply clean power for processes, drive transducers and simulate Europe's 50 Hz power sources.



### FEATURES

- ▶ Output up to 630 watts continuous power into 24 ohms.
- ▶ Front panel indicators for rapid assessment of amplifier status.
- ▶ Designed to survive input overloads, improper output connection (including improper loads) and continuous operation under demanding conditions.
- ▶ Optically isolated, balanced input combined with floating output connectors provide complete isolation from chassis ground.
- ▶ Shipped ready to operate from 100, 120, 220, 230 or 240 -volt single phase, 47-63 Hz, 15 amp, AC power source.
- ▶ Installs easily into a standard 19 inch rack and occupies only 3.5" of rack space.

### INDICATORS AND CONTROLS

- ▶ Front panel LEDs indicate output overload
- ▶ A pushbutton power "On/Off" located on the front panel
- ▶ Two circuit breaker resets on the back panel
- ▶ An input barrier block on the back panel
- ▶ Four output terminals, with 5-way binding posts, on the back panel.



Call us or visit our website! When you want the very best, give us your requirements, and **AE Techron Inc.** will do the rest! We are happy to help.

**AE Techron Inc.**

2507 Warren Street

Elkhart, IN 46516 USA

Phone: 574-295-9495 Fax: 574-295-9496

E-mail: [Sales@aetechron.com](mailto:Sales@aetechron.com), Web: [www.aetechron.com](http://www.aetechron.com)

# LV 3622 SPECIFICATIONS

## PERFORMANCE (One hour continuous ratings)

### Frequency response

dc to greater than 50 kHz, 5-30 kHz +0,-1 dB.

### THD + Noise

Less than 0.10% at 600 hz, full output power

### Residual Noise:

Less than 10 millivolts peak (40 Hz to 600Hz)

### Differential Phase Error

Less than 0.1 degree at 60 Hz. (unit to unit)

### Input Impedance

50.0 kOhms differential

### Output impedance

Less than 10 milliohms in series with less than 2 microhenries

### Output load constraints

24 ohm minimum, 0-90°

### Gain

30 or 60 volts/volt +/- 0.2% internally selectable.

## OUTPUT POWER LV 3622

Bridged Mono	40msec			1 Hour Continuous		
	Ohms	Watts	Volts	Amps	Watts	Volts
4	3505	118	29.6	156	17.7	8.8
8	3140	158	19.8	286	33.6	8.5
16	2250	190	11.9	392	56	7
24	1504	190	7.9	630	123	5.1



## PHYSICAL CHARACTERISTICS

**Chassis:** The Amplifier is designed for stand alone, or rack mounted, operation. The Chassis is black steel with a silver finished aluminum front panel. The unit occupies one EIA 19-inch-wide units.

**Weight:** 56 lbs. (25.4 kg)

**AC Power:** Available in 100, 120, 220, 230, or 240 volt single phase, 47-63 Hz, 15 amperes ac service. Call for more information.)

**Cooling:** Forced air. Intake through removable filters on the front panel, exhaust through side panels.

**Dimensions:** 19 in. x 18.5 in. x 3.5 in (48.3 cm x 46.95 cm x 8.9 cm)

## SUPPORT

When you purchase an **AE Techron** amplifier, a full complement of technical and factory support personnel join your team. **AE Techron Inc.** provides:

- ▶ Applications engineering for your technical questions and customized product needs.
- ▶ A one year limited warranty to protect your equipment investment.
- ▶ A fully equipped service center to keep your amplifier operating at original performance requirements.

## AE Techron Inc.

2507 Warren Street  
Elkhart, IN 46516 USA

Phone: 574-295-9495

Fax: 574-295-9496

E-mail: Sales@aetechron.com

Web: www.aetechron.com