

Service Manual

Pasión Series

Passive Full-Range Karaoke Loudspeaker & Active Subwoofer

- Pasión 6
- Pasión 6F/ JDS-65
- Pasión 8/ JDS-80
- Pasión 10
- Pasión 12
- Pasión 12 SP CN/EU/JDS-SW12







Table of Contents

Datasheets and Specifications

Exploded View Diagrams

Network Assembly Diagrams

Bill of Materials



Passive 6.5" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 6.5" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 100W and sensitivity of 87dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the rotatable JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 6 is a passive 6.5" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 6 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated and rotatable JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 6 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 6 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 6 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 6.5" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 6 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

SYSTEM TYPE: 6.5", 2-way, bass-reflex FREQUENCY RANGE (-10 dB)1: 55 Hz - 17 kHz FREQUENCY RESPONSE (±3 dB)1: 75 Hz - 14 kHz SENSITIVITY (1W@1M)1: 87 dB NOMINAL IMPEDANCE: 8 Ohms MAXIMUM SPL2: 107 dB (113 dB peak) 100 W/200 W/400 W POWER RATING3: (CONTINUOUS/PROGRAM/PEAK)

COVERAGE PATTERN: $100^{\circ} \times 120^{\circ} (H \times V)$

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the rotatable JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 6 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 6 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 6 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS ($H \times W \times D$): 222 mm × 396 mm × 257 mm 8.7 inch × 15.6 inch × 10.1 inch

NET WEIGHT: 7.5 Kg (16.5 lbs) LF DRIVER: 1 × 6.5" Woofer HF DRIVER: 2 × 3" Tweeter INPUT CONNECTORS: Binding Post Vinyl covered MDF **ENCLOSURE CONSTRUCTION:**

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours

www.jblpro.com


Passive 6.5" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH









HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

© 2019 HARMAN International Industries, Incorporated. All rights reserved. Features, specifications and appearance are subject to change without notice.

Pasión 6F

HARMAN

Passive 6.5" Full-Range Karaoke Loudspeaker with Front-Facing Port

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 6F provides venue owners flexible configuration options as it can be mixed

8 Ohms

and matched with other Pasión speakers. The 6F loudspeaker can also be combined with the Pasión 12SP sub via speaker strut to create a portable solution.

SPECIFICATIONS

SYSTEM TYPE: 6.5", 2-way, bass-reflex FREQUENCY RANGE (-10 dB)1: 53 Hz - 17 kHz FREQUENCY RESPONSE (±3 dB)1: 75 Hz - 14 kHz SENSITIVITY (1W@1M)1: 87 dB

MAXIMUM SPL2: 107 dB (113 dB peak) POWER RATING3: 100 W/200 W/400 W

(CONTINUOUS/PROGRAM/PEAK)

NOMINAL IMPEDANCE:

COVERAGE PATTERN: 100° × 120° (H × V) DIMENSIONS ($H \times W \times D$): 222 mm × 396 mm × 257 mm

8.7 inch \times 15.6 inch \times 10.1 inch

NET WEIGHT: 7.5 Kg (16.5 lbs) LF DRIVER: 1 × 6.5" Woofer HF DRIVER: 2 × 3" Tweeter


INPUT CONNECTORS: Spring push type terminal **ENCLOSURE CONSTRUCTION:** Vinyl covered MDF

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling

3 IEC standard, pink noise with 6 dB crest factor for 100 hours

FREQUENCY RESPONSE





BEAMWIDTH





DIMENSIONS


DIMENSIONS IN MM [INCH]













HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Pasión JDS-65

Passive 6.5" Full-Range Karaoke Loudspeaker with Front-Facing Port





KEY FEATURES

- · Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 6.5" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Front-facing low-frequency port provides more installation possibilities
- Rated power of 100W and sensitivity of 87dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the rotatable JBL Entertainment logo
- Combines with the Pasión JDS-SW12 subwoofer via speaker strut for a portable solution

Built with JBL's standard of excellence, the Pasión JDS-65 is a passive 6.5" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión JDS-65 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated and rotatable JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Plus, the Pasión JDS-65 is the only Pasión full-range speaker that features a front-facing low-frequency port, which provides wide bass coverage and added installation options. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión JDS-65 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión JDS-65 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión JDS-65 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 6.5" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

FRONT-FACING LOW-FREQUENCY PORT

Separating itself from other Pasión models, the Pasión JDS-65 is the only full-range speaker in the series to feature a front-facing low-frequency port. With this design, the acoustic port disperses bass across a wide coverage area, which makes

the Pasión JDS-65 perfect for larger karaoke rooms. Also, the front-facing port provides the speaker with added installation options, as venue owners can position the Pasión JDS-65 closer to walls or ceilings for design or space-saving purposes.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión JDS-65 is designed to fit a variety of karaoke venues including commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the rotatable JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión JDS-65 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión JDS-65 is built to sound great for the long haul.

Pasión JDS-65



Passive 6.5" Full-Range Karaoke Loudspeaker with Front-Facing Port

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five full-range speakers and a 12" subwoofer, the Pasión JDS-65 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers. The JDS65 loudspeaker can also be combined with the Pasión JDS-SW12 sub via speaker strut to create a portable solution.

SPECIFICATIONS

SYSTEM TYPE: 6.5", 2-way, bass-reflex FREQUENCY RANGE (-10 dB)1: 53 Hz - 17 kHz

FREQUENCY RESPONSE (±3 dB)1: 75 Hz - 14 kHz SENSITIVITY (1W@1M)1: 87 dB **NOMINAL IMPEDANCE:** 8 Ohms

MAXIMUM SPL2: 107 dB (113 dB peak) POWER RATING3: 100 W/200 W/400 W

(CONTINUOUS/PROGRAM/PEAK)

COVERAGE PATTERN: 100° × 120° (H × V) DIMENSIONS ($H \times W \times D$): 222 mm × 396 mm × 257 mm 8.7 inch \times 15.6 inch \times 10.1 inch

NET WEIGHT: 7.5 Kg (16.5 lbs) LF DRIVER: 1 × 6.5" Woofer HF DRIVER: 2 × 3" Tweeter


INPUT CONNECTORS: Spring push type terminal **ENCLOSURE CONSTRUCTION:** Vinyl covered MDF

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling

3 IEC standard, pink noise with 6 dB crest factor for 100 hours

FREQUENCY RESPONSE





BEAMWIDTH





DIMENSIONS


DIMENSIONS IN MM [INCH]













HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA Made for use in Japan for: DAM

Passive 8" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 8" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 150W and sensitivity of 88dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 8 is a passive 8" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 8 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 8 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 8 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 8 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 8" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 8 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

SYSTEM TYPE: 8°,
FREQUENCY RANGE (-10 dB)¹: 53
FREQUENCY RESPONSE (±3 dB)¹: 70
SENSITIVITY (1W@1M)¹: 88
NOMINAL IMPEDANCE: 8 C
MAXIMUM SPL2: 110
POWER RATING³: (CONTINUOUS/PROGRAM/PEAK)

8", 2-way, bass-reflex 53 Hz - 17 kHz 70 Hz - 14 kHz 88 dB 8 Ohms

110 dB (116 dB peak) 150 W/300 W/600 W

120° × 120° (H × V)

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 8 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 8 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 8 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 253 mm × 452 mm × 277 mm

10.0 inch \times 17.8 inch \times 10.9 inch

 NET WEIGHT:
 8.67 Kg (19.1 lbs)

 LF DRIVER:
 1×8 " Woofer

 HF DRIVER:
 2×3 " Tweeter

 INPUT CONNECTORS:
 Binding Post

 ENCLOSURE CONSTRUCTION:
 Vinyl covered MDF

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours

COVERAGE PATTERN:


Passive 8" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH





HARMAN

HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Pasión JDS-80

Passive 8" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 8" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 150W and sensitivity of 88dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión JDS-80 is a passive 8" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión JDS-80 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión JDS-80 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión JDS-80 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión JDS-80 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 8" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión JDS-80 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

SYSTEM TYPE:
FREQUENCY RANGE (-10 dB)¹:
FREQUENCY RESPONSE (±3 dB)¹:
SENSITIVITY (1W@1M)¹:
NOMINAL IMPEDANCE:
MAXIMUM SPL²:
POWER RATING³:
(CONTINUOUS/PROGRAM/PEAK)

8", 2-way, bass-reflex 53 Hz - 17 kHz 70 Hz - 14 kHz 88 dB

8 Ohms 110 dB (116 dB peak)

150 W/300 W/600 W

 $120^{\circ} \times 120^{\circ} (H \times V)$

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión JDS-80 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión JDS-80 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five full-range speakers and a 12" subwoofer, the Pasión JDS-80 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 253 mm × 452 mm × 277 mm

10.0 inch \times 17.8 inch \times 10.9 inch

 NET WEIGHT:
 8.67 Kg (19.1 lbs)

 LF DRIVER:
 1×8 " Woofer

 HF DRIVER:
 2×3 " Tweeter

 INPUT CONNECTORS:
 Binding Post

 ENCLOSURE CONSTRUCTION:
 Vinyl covered MDF

1 Full space (4) conditions

2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours


COVERAGE PATTERN:

Pasión JDS-80


Passive 8" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH







HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA Made for use in Japan for:

Passive 10" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 3-way, bass-reflex full-range karaoke loudspeaker
- 10" low-frequency woofer, dual 3" high-frequency tweeters and dual 3" mid-range tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 200W and sensitivity of 90dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 10 is a passive 10" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 10 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 10 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 10 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 10 delivers premium sonic performance for KTV applications. The speaker features four 3" high-efficiency tweeters that provide excellent high and mid-range frequency response, while the specially-designed 10" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 10 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

 SYSTEM TYPE:
 10°, 3-way, bass-reflex

 FREQUENCY RANGE (-10 dB)1:
 50 Hz - 17 kHz

 FREQUENCY RESPONSE (±3 dB)1:
 65 Hz - 14 kHz

 SENSITIVITY (1W@1M)1:
 90 dB

 NOMINAL IMPEDANCE:
 8 Ohms

 MAXIMUM SPL2:
 113 dB (119 dB peak)

 POWER RATING3:
 200 W/400 W/800 W

 (CONTINUOUS/PROGRAM/PEAK)

 commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 10 constructed with high-grade components and materials, the loudspeaker also endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 10 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 10 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 292 mm × 521 mm × 320 mm

11.5 inch × 20.5 inch × 12.6 inch

 NET WEIGHT:
 11 Kg (24.3 lbs)

 LF DRIVER:
 $1 \times 10^{\circ}$ Woofer

 HF DRIVER:
 $4 \times 3^{\circ}$ Tweeter

 INPUT CONNECTORS:
 Binding Post

 ENCLOSURE CONSTRUCTION:
 Vinyl covered MDF


1 Full space (4) conditions

2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours


Passive 10" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH



DIMENSIONS





HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Passive 12" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 3-way, bass-reflex full-range karaoke loudspeaker
- 12" low-frequency woofer, dual 3" high-frequency tweeters and dual 3" mid-range tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 250W and sensitivity of 91dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 12 is a passive 12" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 12 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 12 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 12 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 12 delivers premium sonic performance for KTV applications. The speaker features four 3" high-efficiency tweeters that provide excellent high and mid-range frequency response, while the specially-designed 12" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 12 is designed to fit a variety of karaoke venues including

 $120^{\circ} \times 90^{\circ} (H \times V)$

SPECIFICATIONS

 SYSTEM TYPE:
 12", 3-way, bass-reflex

 FREQUENCY RANGE (-10 dB)1:
 47 Hz - 17 kHz

 FREQUENCY RESPONSE (±3 dB)1:
 60 Hz - 14 kHz

 SENSITIVITY (1W@1M)1:
 91 dB

 NOMINAL IMPEDANCE:
 8 Ohms

 MAXIMUM SPL2:
 115 dB (121 dB peak)

 POWER RATING3:
 250 W/500 W/1000 W

 (CONTINUOUS/PROGRAM/PEAK)

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 12 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 12 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 12 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 350 mm × 586 mm × 375 mm 13.8 inch × 23.1 inch × 14.8 inch

 $\begin{array}{lll} \textbf{NET WEIGHT:} & 17.48 \text{ Kg } (38.5 \text{ lbs)} \\ \textbf{LF DRIVER:} & 1 \times 12" \text{ Woofer} \\ \textbf{HF DRIVER:} & 4 \times 3" \text{ Tweeter} \\ \textbf{INPUT CONNECTORS:} & \text{Binding Post} \\ \textbf{ENCLOSURE CONSTRUCTION:} & \text{Vinyl covered MDF} \\ \end{array}$

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours

COVERAGE PATTERN:


Passive 12" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH



HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA



© 2019 HARMAN International Industries, Incorporated. All rights reserved. Features, specifications and appearance are subject to change without notice. **www.jblpro.com**

HARMAN

Pasión 12SP

Powered 12" Karaoke Subwoofer





KEY FEATURES

- Powered 1-way, bass-reflex subwoofer with 12" driver
- Rated power of 300W, frequency response of 30Hz – 300Hz and sensitivity of 95db offer unmatched output and sound quality
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- JBL karaoke tuning provides excellent bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of KTV venues
- Can be combined with Pasión 6F speaker via speaker strut for a portable solution

Built with JBL's standard of excellence, the Pasión 12SP is a powered 12" subwoofer—JBL's first in the KTV range—that is designed for sound reinforcement for karaoke applications. The Pasión 12SP features JBL's signature karaoke tuning that offers outstanding low-frequency response, while its 300W power rating provides plenty of output to bring the karaoke party to the next level. In addition to superb bass performance, the subwoofer features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. With outstanding low-frequency response, excellent output and striking aesthetics, the JBL Pasión 12SP is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate the KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 12SP continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent low-end performance, karaoke-goers will hear accurate and powerful bass while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCEPTIONAL PERFORMANCE

With a specially-designed woofer that is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression, the Pasión 12SP delivers premium low-frequency response and excellent output for KTA applications.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 12SP is designed to fit a variety of karaoke venues including commercial KTV facilities and restaurant entertainment rooms.

SPECIFICATIONS

12" (305 MM) WOOFER

POWER: 300W RMS (450W dynamic)

VOLUME: -∞ - +10dB **FREQUENCY RESPONSE:** 40Hz - 160Hz

CROSSOVER POINT: 40Hz - 160Hz (variable) 24 dB/octave

PHASE: 0° - 180°

 $\begin{array}{lll} \mbox{NPUT:} & \mbox{1x (R+L RCA); 1x XLR} \\ \mbox{OUTPUT:} & \mbox{(Link): 1x (R+L RCA); 1x XLR} \\ \end{array}$

With the JBL Entertainment logo prominently positioned on the grille, venue owners can showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 12SP constructed with high-grade components and materials, the subwoofer also endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 12SP is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which includes five fullrange speakers, the Pasión 12SP provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers. The 12SP can also be combined with the Pasión 6F via speaker strut to create a portable solution.

 SYSTEM TYPE:
 Front facing, bass-reflex

 POWER SUPPLY:
 100~240V 50/60Hz (120V, 60Hz (120V, 60Hz (US); 220~230V, 50/60Hz (EU))

POWER CONSUMPTION (STANDBY): < 0.5W

PROVIDE AN M20 (THREAD) SPEAKER BRACKET MOUNTING HOLE SIZE (W × D × H): $396 \times 464 \times 430 \text{ mm}$


WEIGHT: 22.65KG

Pasión 12SP

Powered 12" Karaoke Subwoofer




FREQUENCY CURVE COMPARSION



DIMENSIONS

DIMENSIONS IN MM [INCH]





HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Pasión JDS-SW12 Powered Subwoofer



PRODUCT INTRODUCTION

Thank you for choosing JBL.

The new JBL Pasión JDS-SW12 Powered Subwoofer integrates a high-performance woofer and built-in high-efficiency amplifier for powerful, deep and accurate low-frequency reproduction. Whether combined with Pasión Series or your favorite full-range speakers, the Pasión JDS-SW12 can greatly enhance music dynamics and sound immersion for a wide range of professional and home entertainment sound reinforcement applications. With variable crossover, phase and volume control, as well as three power switch modes, the Pasión JDS-SW12 is highly adjustable yet easy to set up.


Features

- · Stylish appearance and compact footprint
- · Specially designed high-power 12-inch woofer
- · Cabinet constructed of high-quality board and covered with vinyl layer
- RCA and XLR inputs and thru outputs
- · Variable volume, crossover and phase control
- Three power switch modes: AUTO/OFF/ON

This Quick Start Guide contains all the information related to the setup, connection and operation of this subwoofer. For more detailed information on this product, please visit our website: www.jblpro.com.



DIMENSIONS





PACKING LIST


- 1) 1 × JDS-SW12 Subwoofer
- 2) 1 \times Power Cable (plug type varies by region)
- 3) 1 × Quick Start Guide


SPECIFICATIONS


- Woofer Size: 12" (305 mm)
- Power: 300W RMS (450W dynamic)
- Volume Range: -∞ to +10dB
- Frequency Response: 40Hz 160Hz
- Crossover Frequency: 40Hz 160Hz (variable) 24dB/octave
- Phase: 0° 180° (variable)
- Input: 1x (R+L RCA); 1x XLR
- Output (Link): 1x (R+L RCA); 1x XLR
- System Type: Front facing, bass-reflex
- Power Supply: AC 100-240V, 50/60Hz
- Power Consumption (standby): < 0.5W
- Mounting: M20 (thread) speaker bracket mounting hole
- Dimensions (W×D×H): 396 × 464 × 430 mm
- Weight: 22.65 kg























BS2-RD-02 (附件三)A版




BS2-RD-02 (附件三) A版







保存最新版 BS2-RD-02 (附件三) A版




保存最新版







BS2-RD-02 (附件三)A版





保存最新版 BS2-RD-02 (附件三)A版





BS2-RD-02 (附件三)A版

















Refer to the corresponding Service Bill of Materials (SBOM) to order parts stocked by Harman.