

Service Manual

Pasión Series

Passive Full-Range Karaoke Loudspeaker







Table of Contents

Datasheets and Specifications

Exploded View Diagrams

Network Assembly Diagram

Led Light Board Diagram

Bill of Materials



Passive 6.5" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 6.5" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 100W and sensitivity of 87dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the rotatable JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 6 is a passive 6.5" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 6 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated and rotatable JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 6 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 6 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 6 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 6.5" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 6 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

SYSTEM TYPE: 6.5", 2-way, bass-reflex FREQUENCY RANGE (-10 dB)1: 55 Hz - 17 kHz FREQUENCY RESPONSE (±3 dB)1: 75 Hz - 14 kHz SENSITIVITY (1W@1M)1: 87 dB NOMINAL IMPEDANCE: 8 Ohms MAXIMUM SPL2: 107 dB (113 dB peak) 100 W/200 W/400 W POWER RATING3: (CONTINUOUS/PROGRAM/PEAK)

COVERAGE PATTERN: $100^{\circ} \times 120^{\circ} (H \times V)$

www.jblpro.com

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the rotatable JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 6 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 6 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 6 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS ($H \times W \times D$): 222 mm × 396 mm × 257 mm 8.7 inch × 15.6 inch × 10.1 inch

NET WEIGHT: 7.5 Kg (16.5 lbs) LF DRIVER: 1 × 6.5" Woofer HF DRIVER: 2 × 3" Tweeter INPUT CONNECTORS: Binding Post Vinyl covered MDF **ENCLOSURE CONSTRUCTION:**

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling

3 IEC standard, pink noise with 6 dB crest factor for 100 hours


Passive 6.5" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH







HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

© 2019 HARMAN International Industries, Incorporated. All rights reserved. Features, specifications and appearance are subject to change without notice.

Pasión 6F

Passive 6.5" Full-Range Karaoke Loudspeaker with Front-Facing Port





KEY FEATURES

- · Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 6.5" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Front-facing low-frequency port provides more installation possibilities
- Rated power of 100W and sensitivity of 87dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the rotatable JBL Entertainment logo
- Combines with the Pasión 12SP subwoofer via speaker strut for a portable solution

Built with JBL's standard of excellence, the Pasión 6F is a passive 6.5" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 6F features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated and rotatable JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Plus, the Pasión 6F is the only Pasión full-range speaker that features a front-facing low-frequency port, which provides wide bass coverage and added installation options. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 6F is perfect for a variety of KTV applications and provides karaokegoers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 6F continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 6F delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 6.5" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

FRONT-FACING LOW-FREQUENCY PORT

Separating itself from other Pasión models, the Pasión 6F is the only full-range speaker in the series to feature a frontfacing low-frequency port. With this design, the acoustic port disperses bass across a wide coverage area, which makes the Pasión 6F perfect for larger karaoke rooms. Also, the front-facing port provides the speaker with added installation options, as venue owners can position the Pasión 6F closer to walls or ceilings for design or space-saving purposes.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 6F is designed to fit a variety of karaoke venues including commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the rotatable JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 6F constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 6F is built to sound great for the long haul.

Pasión 6F

UBL ENTERTAINMENT by HARMAN

Passive 6.5" Full-Range Karaoke Loudspeaker with Front-Facing Port

100 W/200 W/400 W

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 6F provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers. The 6F loudspeaker can also be combined with the Pasión 12SP sub via speaker strut to create a portable solution.

SPECIFICATIONS

 SYSTEM TYPE:
 6.5", 2-way, bass-reflex

 FREQUENCY RANGE (-10 dB)1:
 53 Hz - 17 kHz

 FREQUENCY RESPONSE (±3 dB)1:
 75 Hz - 14 kHz

 SENSITIVITY (1W@1M)1:
 87 dB

NOMINAL IMPEDANCE: 8 Ohms
MAXIMUM SPL2: 107 dB (113 dB peak)

POWER RATING3: (CONTINUOUS/PROGRAM/PEAK)

COVERAGE PATTERN: $100^{\circ} \times 120^{\circ} (H \times V)$

DIMENSIONS (H × W × D): 222 mm \times 396 mm \times 257 mm

8.7 inch \times 15.6 inch \times 10.1 inch

NET WEIGHT: 7.5 Kg (16.5 lbs) LF DRIVER: 1×6.5 " Woofer HF DRIVER: 2×3 " Tweeter


INPUT CONNECTORS: Spring push type terminal ENCLOSURE CONSTRUCTION: Vinyl covered MDF

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling

3 IEC standard, pink noise with 6 dB crest factor for 100 hours

FREQUENCY RESPONSE





BEAMWIDTH





DIMENSIONS


DIMENSIONS IN MM [INCH]













HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Passive 8" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 2-way, bass-reflex full-range karaoke loudspeaker
- 8" low-frequency woofer and dual 3" high-frequency tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 150W and sensitivity of 88dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 8 is a passive 8" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 8 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 8 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 8 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 8 delivers premium sonic performance for KTV applications. The speaker features two 3" high-efficiency tweeters that provide excellent high-frequency response, while the specially-designed 8" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 8 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

 SYSTEM TYPE:
 8", 2-wa

 FREQUENCY RANGE (-10 dB)1:
 53 Hz

 FREQUENCY RESPONSE (±3 dB)1:
 70 Hz

 SENSITIVITY (1W@1M)1:
 88 dB

 NOMINAL IMPEDANCE:
 8 Ohms

 MAXIMUM SPL2:
 110 dB

 POWER RATING3:
 150 W/3

 (CONTINUOUS/PROGRAM/PEAK)

8", 2-way, bass-reflex 53 Hz - 17 kHz 70 Hz - 14 kHz 88 dB

110 dB (116 dB peak) 150 W/300 W/600 W

 $120^{\circ} \times 120^{\circ} (H \times V)$

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 8 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 8 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 8 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): $253 \text{ mm} \times 452 \text{ mm} \times 277 \text{ mm}$

10.0 inch × 17.8 inch × 10.9 inch

 $\begin{array}{lll} \textbf{NET WEIGHT:} & 8.67 \text{ Kg } (19.1 \text{ lbs}) \\ \textbf{LF DRIVER:} & 1 \times 8" \text{ Woofer} \\ \textbf{HF DRIVER:} & 2 \times 3" \text{ Tweeter} \\ \textbf{INPUT CONNECTORS:} & \text{Binding Post} \\ \textbf{ENCLOSURE CONSTRUCTION:} & \text{Vinyl covered MDF} \\ \end{array}$

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours

COVERAGE PATTERN:


Passive 8" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH





HARMAN

HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Passive 10" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 3-way, bass-reflex full-range karaoke loudspeaker
- 10" low-frequency woofer, dual 3" high-frequency tweeters and dual 3" mid-range tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 200W and sensitivity of 90dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 10 is a passive 10" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 10 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 10 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 10 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 10 delivers premium sonic performance for KTV applications. The speaker features four 3" high-efficiency tweeters that provide excellent high and mid-range frequency response, while the specially-designed 10" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 10 is designed to fit a variety of karaoke venues including

SPECIFICATIONS

 SYSTEM TYPE:
 10", 3-way, bass-reflex

 FREQUENCY RANGE (-10 dB)1:
 50 Hz - 17 kHz

 FREQUENCY RESPONSE (±3 dB)1:
 65 Hz - 14 kHz

 SENSITIVITY (1W@1M)1:
 90 dB

 NOMINAL IMPEDANCE:
 8 Ohms

 MAXIMUM SPL2:
 113 dB (119 dB peak)

 POWER RATING3:
 200 W/400 W/800 W

 (CONTINUOUS/PROGRAM/PEAK)

COVERAGE PATTERN: $120^{\circ} \times 90^{\circ} (H \times V)$

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 10 constructed with high-grade components and materials, the loudspeaker also endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 10 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 10 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 292 mm × 521 mm × 320 mm

11.5 inch × 20.5 inch × 12.6 inch

 NET WEIGHT:
 11 Kg (24.3 lbs)

 LF DRIVER:
 $1 \times 10^{\circ}$ Woofer

 HF DRIVER:
 $4 \times 3^{\circ}$ Tweeter

 INPUT CONNECTORS:
 Binding Post

 ENCLOSURE CONSTRUCTION:
 Vinyl covered MDF


1 Full space (4) conditions

2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours


Passive 10" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH



DIMENSIONS





HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA

Passive 12" Full-Range Karaoke Loudspeaker





KEY FEATURES

- Passive 3-way, bass-reflex full-range karaoke loudspeaker
- 12" low-frequency woofer, dual 3" high-frequency tweeters and dual 3" mid-range tweeters
- Specially designed low-frequency woofer fitted with demodulating aluminum ring for high-power handling, low distortion and minimum power compression
- Rated power of 250W and sensitivity of 91dB offer unmatched output and sound quality
- JBL signature karaoke tuning provides excellent vocal and bass performance
- Sleek, stylish and modern design that is wellsuited for a wide array of interior room designs
- PSL (Passive Sound Lighting) Technology illuminates the JBL Entertainment logo

Built with JBL's standard of excellence, the Pasión 12 is a passive 12" full-range karaoke loudspeaker that is designed for sound reinforcement for karaoke applications. In addition to superb sound quality, the Pasión 12 features a premium, sleek design that fits a variety of commercial KTV venues and restaurant entertainment rooms. Adding to the stylish form factor, the full-range speaker features an illuminated JBL Entertainment logo, which allows venue owners to showcase the JBL brand and system quality. Altogether, with outstanding vocal and bass performance and striking aesthetics, the JBL Pasión 12 is perfect for a variety of KTV applications and provides karaoke-goers a memorable karaoke experience.

FEATURES

SIGNATURE JBL KARAOKE SOUND

Because superior sound quality can elevate a KTV experience, JBL has emerged as the trusted leader in the karaoke-speaker market. The Pasión 12 continues JBL's KTV heritage with JBL's signature karaoke tuning. Providing excellent vocal and bass performance, karaoke-goers will clearly hear every note while singing their favorite songs.

PREMIUM COMPONENTS FOR EXCELLENT PERFORMANCE

From crystal-clear highs, to powerful accurate lows, the Pasión 12 delivers premium sonic performance for KTV applications. The speaker features four 3" high-efficiency tweeters that provide excellent high and mid-range frequency response, while the specially-designed 12" woofer is fitted with a demodulating aluminum ring for high-power handling, low distortion and minimum power compression.

STYLISH APPEARANCE AND DESIGN

Featuring a premium, sleek form factor, the Pasión 12 is designed to fit a variety of karaoke venues including

 $120^{\circ} \times 90^{\circ} (H \times V)$

SPECIFICATIONS

 SYSTEM TYPE:
 12", 3-way, bass-reflex

 FREQUENCY RANGE (-10 dB)1:
 47 Hz - 17 kHz

 FREQUENCY RESPONSE (±3 dB)1:
 60 Hz - 14 kHz

 SENSITIVITY (1W@1M)1:
 91 dB

 NOMINAL IMPEDANCE:
 8 Ohms

 MAXIMUM SPL2:
 115 dB (121 dB peak)

 POWER RATING3:
 250 W/500 W/1000 W

 (CONTINUOUS/PROGRAM/PEAK)

commercial KTV facilities and restaurant entertainment rooms. The full-range speaker also features PSL (Passive Sound Lighting) Technology, which illuminates the JBL Entertainment logo and allows venue owners to showcase the JBL brand and system quality.

UNCOMPROMISING QUALITY

Not only is the Pasión 12 constructed with high-grade components and materials, the loudspeaker endured JBL's rigorous testing to ensure it will withstand the test of time. With JBL's standard of audio excellence and durability, the Pasión 12 is built to sound great for the long haul.

FLEXIBLE INSTALLATION

As a member of the Pasión Series, which consists of five fullrange speakers and a 12" subwoofer, the Pasión 12 provides venue owners flexible configuration options as it can be mixed and matched with other Pasión speakers.

DIMENSIONS (H × W × D): 350 mm × 586 mm × 375 mm 13.8 inch × 23.1 inch × 14.8 inch

 $\begin{array}{lll} \textbf{NET WEIGHT:} & 17.48 \text{ Kg } (38.5 \text{ lbs)} \\ \textbf{LF DRIVER:} & 1 \times 12" \text{ Woofer} \\ \textbf{HF DRIVER:} & 4 \times 3" \text{ Tweeter} \\ \textbf{INPUT CONNECTORS:} & \text{Binding Post} \\ \textbf{ENCLOSURE CONSTRUCTION:} & \text{Vinyl covered MDF} \\ \end{array}$

1 Full space (4) conditions


2 Calculated maximum SPL based on rated power handling 3 IEC standard, pink noise with 6 dB crest factor for 100 hours

COVERAGE PATTERN:


Passive 12" Full-Range Karaoke Loudspeaker




FREQUENCY RESPONSE



BEAMWIDTH





HARMAN Professional 8500 Balboa Blvd. Northridge, CA 91329 USA





© 2019 HARMAN International Industries, Incorporated. All rights reserved. Features, specifications and appearance are subject to change without notice.


HARMAN

















BS2-RD-02 (附件三)A版




BS2-RD-02 (附件三) A版




保存最新版







保存最新版




保存最新版



BS2-RD-02 (附件三)A版




保存最新版 BS2-RD-02 (附件三)A版



BS2-RD-02 (附件三)A版

LED light board Diagrams



Refer to the corresponding Service Bill of Materials (SBOM) to order parts stocked by Harman.