



MACRO-TECH® SERIES

AC Power Draw and Thermal Dissipation

This document provides detailed information about the amount of power and current drawn from the AC mains by the *Macro-Tech 1202* amplifier and the amount of heat produced under various conditions. The calculations presented here are intended to provide a realistic and reliable depiction of the amplifier. The following assumptions or approximations were made:

- The amplifier's available channels are loaded and full power is being delivered.
- The amplifier efficiency at standard 1-kHz power is estimated to be 65%.
- · Quiescent power draw is approximately 90 watts.
- · Quiescent thermal dissipation equals 105 btu/hr at 90 watts.
- The estimated duty cycles take into account the typical crest factor for each type of source material.
- Duty cycle of pink noise is 50%.
- Duty cycle of highly compressed rock 'n' roll midrange is 40%.
- · Duty cycle of rock 'n' roll is 30%.
- Duty cycle of background music is 20%.
- Duty cycle of continuous speech is 10%.
- Duty cycle of infrequent, short duration paging is 1%.

Here are the equations used to calculate the data presented in Figure 1:

The quiescent power draw of 90 watts is a maximum value and includes power drawn by the fan. The following equation converts power draw in watts to current draw in amperes:

Current Draw (amperes) =
$$\frac{\text{AC Mains Power}}{\text{AC Mains}} \frac{\text{Power}}{\text{Voltage}}$$

The value used for Power Factor is 0.83. The Power Factor variable is needed to compensate for the difference in phase between the AC mains voltage and current. The following equation is used to calculate thermal dissipation:

The value used for inefficiency is 0.35 (1.00–0.65). The factor 3.415 converts watts to btu/hr. Thermal dissipation in btu is divided by the constant 3.968 to get kcal. If you plan to measure output power under real-world conditions, the following equation may also be helpful:

Macro-Tech 1202

	L O A D														
	8 Ohm Stereo					4 Ohm Stereo / 8 Ohm Bridge-Mono / 2 Ohm Parallel-Mono					2 Ohm Stereo / 4 Ohm Bridge-Mono / 1 Ohm Parallel-Mono				
Duty Cycle	AC Mains Power Draw (Watts)	Current Draw (Amps)		Thermal Dissipation		AC Mains Current		aw (Amps)	Thermal Dissipation		AC Mains Power	Current Draw (Amps)		Thermal Dissipation	
		100-120 V	220-240 V	btu/hr	kcal	Draw (Watts)	100-120 V	220-240 V	btu/hr	kcal	Draw (Watts)	100-120 V	220-240 V	btu/hr	kcal
50%	580	5.8	2.9	895	225	850	8.5	4.3	1220	310	1165	11.7	5.9	1595	400
40%	485	4.8	2.4	780	195	700	7.0	3.5	1035	260	950	9.5	4.8	1335	335
30%	385	3.9	2.0	660	165	545	5.5	2.8	855	215	735	7.4	3.7	1080	270
20%	285	2.9	1.5	545	135	395	3.9	2.0	670	170	520	5.2	2.6	820	205
10%	190	1.9	1.0	425	105	240	2.4	1.2	490	125	305	3.1	1.6	565	140

Figure 1 Power Draw, Current Draw and Thermal Dissipation at Various Duty Cycles



H A Harman International Company

Crown International, Inc. PO. Box 1000 Elkhart, IN 46515-1000 TEL: 219-294-8200 FAX: 219-294-8FAX www.crownaudio.com

For more details refer to the applicable Reference Manual or Contact Crown Audio Technical Support. The provided data should not be construed as specifications. Crown and Macro-Tech are registered trademarks of Crown International, Inc. Printed in U.S.A.

© 2000 Crown International, Inc.

08/00 131508-1